

## More Details



## More Structural Features



- Both vents and deadlites have a built-in weep system and external glazing.
- ► A structural silicone is used to glaze the top slope and vertical deadlite portions of
- Snap-in sill cover for seat board provides aesthetic appeal and weather resistance.
- Exterior grade plywood head board, seat board and jamb are 1-1/4-inch for improved structural and thermal performance; support brackets are not needed.
- ➤ Engineered for new construction and remodeling applications.
- > Standard garden window jamb depths of 4-9/16, 5-1/4, 6-9/16, and 11 inches are available as well as custom jamb depths to fit any application.

## Operating Sash

- ➤ Locks and operators are conveniently mounted to the inside front area for easy access.
- Operators are sealed to prevent air and water infiltration.
- ► Twin sealing, fully screened, operating casements with external glazing for improved
- ➤ The multi-point locking system provides a tighter seal and added security.

## More Options

- ➤ Glass options include high performance Low-E and v-groove, along with a variety of grid designs.
- ➤ Highly recommended: Insulation board with an "R" value of 5 can be installed under the seat board to increase the "R" value to 6.22. This 1-inch thick lightweight rigid material is 100 percent waterproof. Note: Insulation board is required for all painted units.
- ➤ One or more adjustable glass shelves with polished edges, brackets and standards. Depending upon the width of the unit, the glass thickness will be either 3/8-inch or 1/2-inch.



\*Although units of a larger size do not have the same R-50 "Coastal Rating," they still provide all of the features and options of the smaller sizes. The color samples shown here are reproduced by mechanical process and may vary from actual colors of the product. Please contact your sales representative

publication, some changes may have occurred. Please check with your sales





### Series 2051 Stucco Replacement Garden Window

Designed specifically for stucco remodeling applications, the Series 2051 garden window installs like a new construction window. It incorporates aluminum nail flanges for mounting directly to the outside of the existing window framing (knee braces are required for support). The sill flange can be mounted prior to window placement which aids installation of the unit. A major advantage of this design is that there is no disruption to the interior wall treatment. Ask your sales representative for more











Open Up Your Space, Add Light Series 2050 Garden Window









Each window is custom made to your specifications and is shipped completely assembled, ready to install.

The Series 2050 is the only vinyl garden window on the market today with an AAMA certified DP-50 (R-50) rating for units 60.5 x 60.5 inches and smaller.\*

- > Fully welded, rigid PVC frame for greater strength and stability.
- ➤ Vinyl frame will not chip, rot or peel and will never need to be painted.
- ➤ Clear 1-inch insulated glass package.
- ➤ Top slope insulating glass (a constant 35-degree pitch) is tempered for improved safety and unit integrity.
- ➤ The projection of the window from the exterior wall face is a constant 17 inches.
- ➤ Knee brace supports are not needed.

# Beautify Your Home

Open up any space in your home with a garden window and create a beautiful setting for your plants, collectibles or decorations. It could be the perfect finishing touch for your kitchen, bath or den make-over, remodeling project or new home.

The fully screened twin sealing side vents open a full 90 degrees to allow those warm breezes in on a sunny day. The multi-point locking system keeps out the cold and provides a tighter seal for added security.



## Headboard, Seat Board and Jamb Colors



Acrylic Solid Surface Seat Board Colors



## Colors and Options

- > Standard frame colors are White and Tan. Other colors are available by special order, including: Champagne or Cocoa exterior with a White interior or White exterior with a Light Oak interior.
- ➤ Also available as a special order option is our color match system which allows the window to be painted to match your color sample.
- ➤ Head board, seat board, and jamb are available in Birch or Oak veneer and White or Tan high-pressure laminate. Special order interior options include, Light Oak, Dark Oak or Cherry high-pressure laminate.
- ➤ Windows with a Birch or Oak interior can be provided pre-stained with a variety of Minwax<sup>®</sup> stains and sealed.

- ➤ An acrylic solid surface seat board is available in Arctic White and decorator colors: Almond, Vanilla Sugar, Platinum Granite, Black Pearl or White Quartz.
- ➤ As shown in the window on the front cover: Interior LED lighting that is cool to the touch (hard wired only).
- ➤ The optional "Bullnose Edging and Interior Trim Kit" provides pre-cut casing and valance.



Valance and bullnose edging detail